



# Product data sheet

Issue date: 27/06/24



# Microriccio flat mop with strap tape system

Microfibre flat mop looped end with strap tape system support



Technical information								
code	notes	cm (comm. sizes)	cm (real sizes)	С	pcs	kg	m³	
0M000707	white with blue support	<i>J</i> 30 <i>J</i> 10,5	J 31 J 10		25	1,81	0,011	
0M000705	white with blue support	J 40 J 10,5	J 44 J 10		25	2,43	0,014	
0M000706	white with blue support	<i>→</i> 60 <i>→</i> 10,5	J 64 J 10		25	3,47	0,03	
0RR00745MR	red with red support	J 40 J 10,5	J 44 J 10		25	2,43	0,014	
0BB00745MB	blue with blue support	<i>J</i> 40 <i>J</i> 10,5	J 44 J 10		25	2,43	0,014	
0VV00745MV	green with green support	J 40 J 10,5	J 44 J 10		25	2,43	0,014	
0GG00745MG	yellow with yellow suppport	<i>J</i> 40 <i>J</i> 10,5	J 44 J 10		25	2,43	0,014	
0RR00746MR	red with red support	J 60 J 10,5	J 64 J 10		25	3,54	0,03	
0BB00746MB	blue with blue support	<i>J</i> 60 <i>J</i> 10,5	J 64 J 10		25	3,54	0,03	
0VV00746MV	green with green support	<b>.</b>	J 64 J 10		25	3,54	0,03	
0GG00746MG	yellow with yellow suppport	J 60 J 10,5	J 64 J 10		25	3,54	0,03	

SYSTEM

Flat mopping system with frame with strap tape system, to be used either presoaked, soaked on demand with soaking station or with handles with tank Ideal for any surface and for particle dirt thanks to the high dirt collection power of yarn and microfibre

GREEN BOX					
	<b>DECITEX of the fibres</b> Microfibre: 0,58 DTX				
(IS)	<b>Efficient:</b> microfibre requires less chemical to remove dirt and bacteria, reducing water and chemical consumption				
	Code 0M000705 is classified as having a low release of microplastics during washing (test conducted according to ISO 23231 by a specialised external laboratory)				





27/06/24

### **Analysis**

The analysis of the mechanical action of the Microriccio mop revealed a removal of Coronavirus 229E from steel surfaces of 99.9% (test conducted by a specialised external laboratory)

Analysis of codes 0M000707, 0M000705 and 0M000706 revealed a removal of up to 98.79% of the bacteria present on the surface (test conducted by a specialised external laboratory)

### Advantages

- Easy: mop changing is easy and quickly
- **Ergonomic:** it is the most lightweight system of TTS range
- · Highest hygiene: microfibre penetrates into the microporosity of the floor, collecting dirt and more than 95% of bacteria
- Long durability: high quality strap tape to ensure a long life of the mop

#### Material

Yarn: microfibre (100% polyester) - Support: polyester

Packaging: click here to see the environmental labelling of packaging

### Washing conditions

#### Guidelines for proper fibre maintenance

Follow the washing instructions (temperatures and dosage) on the laundry detergent packaging

Perform a pre-wash in cold water without laundry detergent to remove any residual product used during cleaning operations

Recommended use of professional textile laundry detergent

Do not use fabric softener

Do not use laundry detergents with Ph> 11

The use of laundry nets is recommended to speed up and make laundry operations more hygienic

#### Specific mop instructions



Washing temperature max 90° C, recommended 60°



Bleaching possible, do not use chlorine



Tumble dry or in a dryer possible with low program





27/06/24

# Related products



Velook frame



Velook frame with Block System



BIO Pro with strap tape system



BIO Basic with strap tape system



Clean Glass frame

## **Product options**



Microsplit 32 flat mop with strap tape system



Flat mop Microblue with strap tape system